

Wayne Johnson

From: "Dan Bauer" <bauer@fnal.gov>
To: "Dennis SEITZ" <dseitz@cosmology.berkeley.edu>; "Wayne JOHNSON" <wjohnson@fnal.gov>; "Fritz DeJongh" <fritzd@fnal.gov>
Cc: <hansen@fnal.gov>
Sent: Thursday, November 17, 2005 8:49 AM
Subject: Soudan FEB settings

Hi Dennis, Wayne, Sten, and Fritz,

I'm not sure who is the current editor of the spreadsheet Wayne started concerning FEB settings, but I had promised to look up the standard operating settings from Soudan. We should have a column for these, and a separate column for test facilities, which use a wider range of settings. Here's the sequence we normally use at Soudan:

Begin run configuration

- For each detector
 - Unlock SQUIDS
 - Set SQUID ZAP voltage to 0
- For each phonon channel
 - Set QET bias to ~ 120 uA (typically ± 80 uA)
 - Set SQUID bias to -85 uA (± 20 uA)
 - Set SQUID lockpoint to ~ 2 mV (± 0.5 mV)
 - Set SQUID open loop gain to 20 (occasionally 10 or 50)
 - Set SQUID output offset to 0 (± 2 V)
- Turn Auto Zero ON
- Unlock SQUIDS
- Set Charge Bias state to GROUND
- Set LED Bias to ~ 200 uA (ranges 100-5000, either polarity)
- Set LED to multi-pulse mode (and again ground charge)
- Set LED Pulse width to ~ 500 us (± 1 ms)
- Set LED rep rate to ~ 3 ms (± 10 ms)
- Fire LED and wait 0.025 minutes
- Turn off LED
- Set LED Bias to 0

Begin data taking sequence

- Set charge biases to 3-6V, either polarity
- Set charge gain to 10
- Set charge output offsets to 0 (using Autozero)
- Unlock SQUIDS
- Lock SQUIDS
- Take data

Every few hours during data taking

- Pause data
- Ground charge channels
- Unlock SQUIDS
- Go through LED flashing as above
- Go through charge bias and SQUID relocking as above
- Resume data

Dan